ELECTRONIC CASH REGISTER

TE-1500 THANK OU THANK RECEIPT YOUR RECEIPT CALL AGAIN !



USER'S MANUAL


CASIO.

Introduction & Contents


Important!

Your new cash register has been carefully tested before shipment to ensure proper operation. Safety devices eliminate worries about breakdowns resulting from operator errors or improper handling. In order to ensure years of trouble-free operation, however, the following points should be noted when handling the cash register.


Do not locate the cash register where it will be subjected to direct sunlight, high humidity, splashing with water or other liquids, or high temperature (such as near a heater).




Be sure to check the sticker on the side of the cash register to make sure that its voltage matches that of the power supply in the area.




Never operate the cash register while your hands are wet.



Use a soft, dry cloth to clean the exterior of the cash register. Never use benzene, thinner, or any other volatile agent.





Welcome to CASIO Cash Register!

Congratulations upon your selection of a CASIO Electronic Cash Register, which is designed to provide years of reliable operation.

Operation of a CASIO cash register is simple enough to be mastered without special training. Everything you need to know is included in this manual, so keep it on hand for reference.

Consult your CASIO dealer if you have any questions about points not specifically covered in this manual.

GUIDELINES LAID DOWN BY FCC RULES FOR USE OF THE UNIT IN THE U.S.A. (Not applicable to other areas)

WARNING: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Please keep all information for future reference.

The main plug on this equipment must be used to disconnect mains power.

Please ensure that the socket outlet is installed near the equipment and shall be easily accessible.

Introduction & Contents

Safety Precautions

• To use this product safely and correctly, read this manual thoroughly and operate as instructed.

After reading this guide, keep it close at hand for easy reference.

Please keep all informations for future reference.

• Always observe the warnings and cautions indicated on the product.

About the icons

In this guide various icons are used to highlight safe operation of this product and to prevent injury to the operator and other personnel and also to prevent damage to property and this product. The icons and definitions are given below.



Indicates that there is a risk of severe injury or death if used incorrectly.



Indicates that injury or damage may result if used incorrectly.

Icon examples

To bring attention to risks and possible damage, the following types of icons are used.



The \triangle symbol indicates that it includes some symbol for attracting attention (including warning). In this triangle the actual type of precautions to be taken (electric shock, in this case) is indicated.



The \otimes symbol indicates a prohibited action. In this symbol the actual type of prohibited actions (disassembly, in this case) will be indicated.



The symbol indicates a restriction. In this symbol the type of actual restriction (removal of the power plug from an outlet, in this case) is indicated.

⚠ Warning!

Handling the register



Should the register malfunction, start to emit smoke or a strange odor, or otherwise behave abnormally, immediately shut down the power and unplug the AC plug from the power outlet. Continued use creates the danger of fire and electric shock.

• Contact CASIO service representative.



Do not place containers of liquids near the register and do not allow any foreign matter to get into it. Should water or other foreign matter get into the register, immediately shut down the power and unplug the AC plug from the power outlet. Continued use creates the danger of shorting, fire and electric shock.

• Contact CASIO service representative.



Should you drop the register and damage it, immediately shut down the power and unplug the AC plug from the power outlet. Continued use creates the danger of shorting, fire and electric shock.

• Attempting to repair the register yourself is extremely dangerous. Contact CASIO service representative.



Never try to take the register apart or modify it in any way. High-voltage components inside the register create the danger of fire and electric shock.

• Contact CASIO service representative for all repair and maintenance.

⚠ Warning!

Power plug and AC outlet



Use only a proper AC electric outlet (100V~240V). Use of an outlet with a different voltage from the rating creates the danger of malfunction, fire, and electric shock. Overloading an electric outlet creates the danger of overheating and fire.



Make sure the power plug is inserted as far as it will go. Loose plugs create the danger of electric shock, overheating, and fire.

• Do not use the register if the plug is damaged. Never connect to a power outlet that is loose.



Use a dry cloth to periodically wipe off any dust built up on the prongs of the plug. Humidity can cause poor insulation and create the danger of electric shock and fire if dust stays on the prongs.

Never use detergent to clean the power cord, especially the plug and jack.



Do not allow the power cord or plug to become damaged, and never try to modify them in any way. Continued use of a damaged power cord can cause deterioration of the insulation, exposure of internal wiring, and shorting, which creates the danger of electric shock and fire.

• Contact CASIO service representative whenever the power cord or plug requires repair or maintenance.





Do not place the register on an unstable or uneven surface. Doing so can cause the register — especially when the drawer is open — to fall, creating the danger of malfunction, fire, and electric shock.

Do not place the register in the following areas.



- Areas where the register will be subject to large amounts of humidity or dust, or directly exposed to hot or cold air.
- Areas exposed to direct sunlight, in a close motor vehicle, or any other area subject to very high temperatures.

The above conditions can cause malfunction, which creates the danger of fire.



Do not overlay bend the power cord, do not allow it to be caught between desks or other furniture, and never place heavy objects on top of the power cord. Doing so can cause shorting or breaking of the power cord, creating the danger of fire and electric shock.



Be sure to grasp the plug when unplugging the power cord from the wall outlet. Pulling on the cord can damage it, break the wiring, or cause short, creating the danger of fire and electric shock.



Never touch the plug while your hands are wet. Doing so creates the danger of electric shock. Pulling on the cord can damage it, break the wiring, or cause short, creating the danger of fire and electric shock.

Never touch the printer head, platen and cutter.

Introduction & Contents

Introdu	uction & Contents	2
	g Started	
Oottiii	Load the memory protection batteris and Paper rolls	
	Install receipt / journal paper	
	3. Plug the cash register into a wall outlet.	
	4. Insert the mode key marked "PGM" into the mode switch	13
	5. Turn the mode switch to the "PGM" position	
	6. Set the date.	
	7. Set the time.	
	8. Tax table programming	
	·	
	9. Select watermark on receipt.	
	10. Department unit price programming	
	11. PLU unit price programming	
	12. Discount rate programming	
	13. Issuing daily reset report	
	14. Advanced operations and Setups	
	15. Issuing reports	
	16. Troubleshooting	
Introdu	ucing the Register	20
	General guide	20
	Roll paper	20
	Mode key	20
	Drawer	
	Drawer lock / Drawer key	
	Magnetic plate	
	How to set the Pop-up display	
	Display	
	Display panel	
	Main display	
	Customer display	
	Keyboard	
Basic	Operations and Setups	26
	How to read the printouts	26
	How to use your cash register	27
	Before business hours	28
	Checking the time and date	28
	To display and clear the date/time	
	Preparing coins for change	
	Preparing and using department keys	
	Registering department keys	
	Programming department keys	
	To program a unit price for each department	
	To program the tax calculation status for each department	
	To program high amount limit for each departmentRegistering department keys by programming data	
	Preset price	
	Preset tax status	
	Locking out high amount limitation	
	Preparing and using PLUs	
	Programming PLUs	33
	To program a unit price for each PLU	33
	To program tax calculation status for each PLU	
	Registering PLUs	34

	Preparing and using discounts	36
	Programming discounts	36
	Registering discounts	36
	Discount for items and subtotals	. 36
ĺ	Preparing and using reductions	37
	Programming for reductions	37
	To program preset reduction amount	
	Registering reductions	37
	Reduction for items and subtotal	. 37
	Registering credit and check payments	38
	Check	
	Charge	
	Credit	
	Mixed tender (cash and check)	
,	Shifting the taxable status of an item	აყ ვი
	Calculation merchandise subtotal	
	Registering returned goods in the REG mode	
	Registering returned goods in the RF mode	
	Registering money received on account	
	Registering money paid out	
	No sale registration	
	Making corrections in a registration	
	To correct an item you input but not yet registered	
	To correct an item you input and registered	
	To cancel all items in a transaction	
	Printing the daily sales reset report	
Advanc	ed Operations	46
	Jsing clerk functions	46
	Enable clerk feature	46
	Assigning a clerk	46
	Clerk number key	. 46
;	Single item cash sales	47
(Currency exchange function	48
	Registering foreign currency	48
	Full amount tender in foreign currency	
	Partial tender in a foreign currency	
	Premium	
ļ	Programming department / PLU descriptors and preset messages in the list	
	How to choose and set the department / PLU descriptors in the list	
	How to choose and set the preset receipt message and graphic logo in the list	
	Preset message and graphic print sample	
	Character manual input	
	Entering characters	
	Using character keyboard	
1	Entering characters by multi tapping	
	Programming descriptors and messages by entering characters	
	Programming PLU descriptor	
	Programming department / function key descriptor	
	Function key Department key	
	Programming message	
	Receipt message	
	Programming Clerk name	
	Clerk name	

Introduction & Contents


Programming other descriptors	
Report descriptor	
Grand total, special character	
Report title	
Machine feature program	60
General control program	60
Programming procedure	
Program data (by address code)	
Address code 02 (machine number)	
Address code 03 (consecutive number)	
Address code 04 (tax system)	
Address code 05 (print control for receipt)	
Address code 06 (calculation & operation control)	
Address code 08 (print control for fixed total report)	
Address code 10 (print control for taxable amount)	
Address code 14 (currency exchange control)	63
Address code 15 (print control for reports)	
Address code 16 (print control for grand total)	64
Address code 17 (print control)	64
Address code 19 (receipt control)	64
Address code 21 (message control)	64
Address code 27 (clerk control)	65
Address code 30 (thermal printer control)	65
Address code 34 (backlight control)	65
Key function program	66
Department key/PLU program (Batch feature programming)	
Programming procedure	66
Program data	
Department key/PLU program (Individual feature programming)	
Programming procedure	
Program data (by address code)	
Transaction key program	
Programming procedure	
Program data	
Clerk program	
Clerk number, check number programming	
Clerk other programming	
Printing read/reset reports	74
To print the individual department, PLU read report	74
To print daily read reports	
To print daily reset reports	
Read / reset report sample	
To print the periodic 1/2 sales read/reset reports	
Reading the cash register's program	82
To print unit price/rate program (except PLU)	
To print key descriptor, name, message program (except PLU)	
To print the machine program (except PLU)	83
To print the PLU unit price	
To print the PLU descriptor	
To print the PLU program	

Troubleshooting	86
When an error occurs	
When the register does not operate at all	88
Clearing a machine lock up	
In case of power failure	89
When the L sign appears on the display	
User Maintenance and Options	
To replace journal paper	
To replace receipt paper	
Options	
Specifications	92
Index	93

This chapter shows how to setup the cash register and get it ready to operate. Please read this chapter even if you have used a cash register before.

1. Load the memory protection batteris and Paper rolls

Load the two memory protection batteries



1. Remove the printer cover and open the platen arm (receipt side).



2. Remove the battery compartment cover.



platen arm

battery compartment cover





3. Note the (+) and (–) markings in the battery compartment. Load a set of two new alkaline batteries so that their positive (+) and negative (-) ends are facing as indicated by the markings.





No battery is included in the accessories.

- 4. Replace the battery compartment cover.
- 5. Close the platen arm and replace the printer cover.

Important!


These batteries protect information stored in your cash register's memory when there is a power failure or when you unplug the cash register. Be sure to install these batteries.

WARNING!

- Never try to recharge the batteries supplied with the unit.
- Do not expose batteries to direct heat, let them become shorted or try to take them apart.

Keep batteries out of the reach of small children. If your child should swallow a battery, consult a physician immediately.

2. Install receipt / journal paper.



Important!

Take away the head protection sheet from the printer and close the platen arm.

Caution! (in handling the thermal paper)

- Never touch the printer head and the platen.
- Unpack the thermal paper just before your use.
- Avoid heat/direct sunlight.
- Avoid dusty and humid places for storage.
- Do not scratch the paper.
- Do not keep the printed paper under the following circumstances: High humidity and temperature/direct sunlight/contact with glue, thinner or a rubber eraser.

To install receipt paper



Step 1 Remove the printer cover.



Step 4

Put the leading end of the paper over the printer.



Step 2 Open the platen arm.



Step 5

Close the platen arm slowly until it locks steadily.



Step 3

Ensuring the paper is being fed from the bottom of the roll, lower the roll into the space behind the printer.



Complete

Replace the printer cover, passing the leading end of the paper through the cutter slot. Tear off the excess paper.

To install journal paper



Step 1 Remove the printer cover.



Step 2 Open the platen arm.



Step 7 Slide the leading end of the paper into the groove on the spindle of the takeup reel and wind it onto the reel two or three turns.



Step 3 Ensuring the paper is being fed from the bottom of the roll, lower the roll into the space behind the printer.




Step 8 Replace the paper guide of the take-up reel.



Step 4 Put the leading end of the paper over the printer.



Step 9 Place the take-up reel into place behind the printer, above the roll paper.



Step 5 Close the platen arm slowly until it locks steadily.



Step 10 Press the FEED key to take up any slack in the paper.



During machine installation, press the | JOURNAL | FEED | key after power on.



Step 6 Remove the paper guide of the take-up reel.




Complete Replace the printer cover.

3. Plug the cash register into a wall outlet.




Be sure to check the sticker (rating plate) on the side of the cash register to make sure that its voltage matches that of the power supply in your area.

4. Insert the mode key marked "PGM" into the mode switch.





5. Turn the mode switch to the "PGM" position.



When the display shows "Low battery", load memory protection batteries (refer to page 10).

6. Set the date.

- 1. Enter current date in year month day order, and press the <X/FOR> Example: June 15, $2008 \Rightarrow 0 \mid 8 \mid 0 \mid 6 \mid 1 \mid 5 \mid$
- 2. Press $\langle C \rangle$ key. Example: **C**

7. Set the time.

- 1. Enter current time in 24 hour system, and press the <X/FOR> Example: $08:30 \text{ AM} \Rightarrow 0 \mid 8 \mid 3 \mid 0 \mid_{\text{date}}^{\text{x/for}} \qquad (9:45 \text{ PM} \Rightarrow 2 \mid 1 \mid 4 \mid 5 \mid_{\text{date}}^{\text{x/for}})$
- 2. Press $\langle C \rangle$ key. Example: **C**

8. Tax table programming

Programming automatic tax calculation

Important!


After you program the tax calculations, you also have to individually specify which departments (page 32) and PLUs (page 33) are to be taxed.

For this cash register to be able to automatically register state sales tax, you must program its tax tables with tax calculation data from the tax table for your state. There are three tax tables (U. S.) and four tax tables (Canada) that you can program for automatic calculation of three/four separate sales taxes.

Programming for the U.S. tax tables procedure


There are two ways to set up the U.S. tax tables:

A) Input the desired tax rate / Changing the tax rate




B) Choose the tax rate from a preset tax table.

The procedure to setup the tax table is printed on the guidance receipt. First issue the guidance receitpt by the HELP key and follow it to set the tax table.



8. Tax table programming (continued)

Programming Canadian tax table



• 4 tax tables are used for the following purpose

Table 1: Used for the federal taxable items.

Table 2: Used for the provincial taxable items.

Table 3/4: Used for the provincial taxable items for different tax table.

Important!

Be sure you use the federal sales tax data with your provincial sales tax data. Even if your province use the same tax rate as another province, inputting the wrong data will result incorrect tax calculations.

9. Select watermark on receipt.

Turn the mode switch to "PGM", enter <0> or <1>, and press the <CH>, <ST>

Example: no watermark

O CH SUB

with watermark

1 CH SUB TOTAL

NOTE:

After completion of register programming, enter 6 2 0 0 and sub in the PGM 7 mode (PGM mode \Rightarrow 7 $\frac{\text{SUB}}{\text{TOTAL}}$) to backup the program data into the internal non-volatile memory.

(This opration takes about 30 seconds.)

10. Department unit price programming

Maximum 6-digit unit price can be set to the department.

Refer to page-32.

Tax calculation status can be set to the department.

Refer to page-32.

11. PLU unit price programming

Maximum 6-digit unit price can be set to the PLU.

Refer to page-33.

Tax calculation status can be set to the PLU.

Refer to page-33.

12. Discount rate programming

0.01 - 99.99% rate can be set to the Discount key.

Refer to page-36.

Tax calculation status can be set to the Discount key.

Refer to page-36.

13. Issuing daily reset report

After business hours, issue daily reset report.

Refer to page-45.

Getting Started

14. Advanced operations and Setups

Using clerk functions	46
Single item cash sales	47
Currency exchange function	48
Premium	50
Department / PLU name selection / set	52
Preset message /graphic selection / set	52
Character manual input	53
Machine feature program	60
Key function program	66

15. Issuing reports

Individual item read report74
Daily read report
PLU report75
Monthly report75
Hourly report75
Group report75
Flash report75
Daily reset report
Periodic sales report 80
Program read report 82


16. Troubleshooting

E sign appears	86
Drawer does not open	87
L sign appears	89
To replace receipt / journal paper 90,	91

Introducing the Register

General guide

This part of the manual introduces you to the cash register and provides a general explanation of its various parts.




Roll paper

You can use the roll paper to print receipts and a journal (page $11 \sim 12$).

Mode key

There are two types of mode keys: the program key (marked "PGM") and the operator key (marked "OP"). The program key can be used to set the mode switch to any position, while the operator key can select the **REG** and **OFF** position.







Program key

Drawer

The drawer opens automatically whenever you finalize a registration and whenever you issue a read or reset report. The drawer will not open if it is locked with the drawer key.

Drawer lock / Drawer key


Use the drawer key to lock and unlock the drawer.



Drawer key


Magnetic plate

Use this plate for tacking the notes received from customer.



Mode switch


Use the mode keys to change the position of the mode switch and select the mode you want to use.




Mode Switch	Mode Name	Description		
X2/Z2 Periodic sale read/reset		Used to obtain periodic sales reports without resetting total data or while resetting all total data.		
Z Daily sales reset Used to obtain daily reports while resetting (clearing) total data.		Used to obtain daily reports while resetting (clearing) all total data.		
X Daily sales read Used to obtain daily reports without resetting (clearing) all data.		Used to obtain daily reports without resetting (clearing) all total data.		
REG	REG Register Used for normal registration.			
OFF	Stand-by	Cash register standing by.		
RF	Refund	Tund Used for registering refund transaction.		
PGM	Program	Used for cash register programming.		

How to set the Pop-up display

1. Lift the unit until it stops.



2. Rotate the unit.




Introducing the Register


Display

Display panel

Main display



Customer display




Displays

Main Display

(alphanumeric + numeric display)

Item registration (by department/PLU)





Pop-up (customer) display

(numeric display)




Repeat registration





Totalize operation





1) Item count and subtotal

This part of the display shows item sold count and subtotal.

(2) Item / Key / Change descriptor

When you register an item or key, the item / key / change descriptor appears here.

Mode descriptor is also displayed here.

(3) Amount / Quantity

This part of the display shows monetary amounts. It also can be used to show the current time. (The current date is shown in the alphanumeric display.)

(4) Taxable sales status indicators

When you register a taxable item, the corresponting indicator is lit.

(5) Number of repeats

Anytime you perform a repeat registration (page 29, 34), the number of repeats appears here. Note that only one digit is displayed for the number of repeats. This means that a "5" could mean 5, 15 or

even 25 repeats.

(6) Tendered amount

When the tender operation is made, the entered value appears here.


(7) Total / Change indicators

When the TOTAL indicator is lit, the displayed value is monetary total or subtotal amount.

When the CHANGE indicator is lit, the displayed value is the change due.

Introducing the Register

Keyboard



- 1 Paper feed key | RECEIPT |, | JOURNAL | FEED | Hold this key down to feed paper from the printer.
- 2 Ten key pad $[0, 1, \sim 9, 00, \cdots]$ Use these keys to input numbers.
- (3) Clear key C Use this key to clear an entry that has not yet been registered.
- 4 Cash amount tendered key CA/ANT Use this key to register a cash sale.
- (5) Check key CHK Use this key to register a check tender.
- 6 Subtotal kev SUB Use this key to display and print the current subtotal (includes add-on tax) amount.
- (7) Help key HELP Use this key to look up the procedures to set date/time, tax table etc.
- 8 Tax program key PGM Use this key to set the tax status and tax table.
- 9 Clerk number key CLK# Use this key to sign clerk on and off the register.
- 10 Sign off key SIGN OFF Use this key to sign clerk off the register.
- Use this key following a numeric entry to register money received for non-sale transactions.

- 12 Paid out key | PD Use this key following a numeric entry to register money paid out from the drawer.
- (13) Reduction (minus) key | -Use this key to input values for reduction.
- (14) Discount key \[\%-Use this key to register discounts.
- (15) **Receipt on/off key** RECEIPT ON/OFF Use this key twice to change the status "receipt issue" or "no receipt."
- (16) Price key PRICE Use this key to register unit prices for subdepartment. (17) PLU/Subdepartment key | S.DEPT |
- Use this key to input PLU (subdepartment) numbers. (18) **Refund key** | RF Use this key to input refund amounts and void certain
- 19 Multiplication/For/Date/Time key | X/FOR / DATE Use this key to input a quantity for a multiplication and registration of split sales of packaged items. Between
- transactions, this key displays the current time and date. 20 Error correct / Cancel key CANCEL Use this key to correct registration errors and to cancel registration of entire transactions.
- (1) Received on account key | RC 21) Post receipt key POST RECEIPT Use this key to produce a post-finalization receipt.

2 Department keys	_1	, [_	2	 ,~
Use these keys to regi	ster	iten	ns t	to departments

② Charge key CH Use this key to register a charge sale.

24 Currency exchange key | CE

Use this key for calculating subtotal amounts or paying amount due in foreign currency.

25 Premium key [%+] Use this key to register premiums.

26 Open key OPEN

Use this key to temporarily release a limitation on the number of digits that can be input for a unit price.

② Department no. / Department shift key

Department no.: Use this key to input department numbers.

Department shift: Use this key to shift the department key number from 1 through 30 to 31 through 60.

1]

□ Dept 01 1] ⇒ Dept 31

28 Tax shift 1 key [T/S1]

Use this key without a numeric entry to change the Taxable 1 status of the next item.

29 Tax shift 2 key [T/S2]

Use this key without a numeric entry to change the Taxable 2 status of the next item.

30 Non-add / No sale key | #_Ns|

Non-add key: Use this key to print reference number (to identify a personal check, credit card, etc.) during a transaction, use this key after some numerical entries. No sale key: Use this key to open the drawer without registering anything.

31 Credit key CR Use this key to register a credit sale.

32 Enter key ENTRY (future use)


Basic Operations and Setups

How to read the printouts

- The journal / receipts are records of all transactions and operations.
- The contents printed on receipts and journal are almost identical.
- You can choose the journal skip function.

If the journal skip function is selected, the cash register will print the total amount of each transaction, and the details of premium, discount and reduction operations only, without printing department and PLU item registrations on the journal.

- The following items can be skipped on receipts and journal.
 - Taxable status
 - Taxable amount
 - Item counter




^{*1} You can choose to print preset message and graphic at the top of the receipt or at the bottom of the receipt.

In the operation examples contained in this manual, the print samples are what would be produced if the roll paper is being used for receipts. They are not actual size. Actual receipts are 58 mm wide. Also, all sample receipts and journals are printout images.

How to use your cash register

The following describes the general procedure you should use in order to get the most out of your cash register.

BEFORE business hours...




- Check to make sure that the cash register is plugged in securely. Page 13
- Check to make sure there is enough paper left on the roll. Pages 11, 12
- Read the flash report to confirm that totals are all zero.
- Check the date and time. Page 28

DURING business hours...

- Register transactions.
- Periodically read totals.

Page 29 -

Page 74



AFTER business hours...



- Reset the daily totals. Page 45, 76
- Remove the journal.

Page 90

Empty the cash drawer and leave it open.


Page 20

Page 75

Take the cash and journal to the office.


Before business hours

Checking the time and date




You can show the time or date on the display of the cash register whenever there is no registration being made.

To display and clear the date/time



Preparing coins for change



You can use the following procedure to open the drawer without registering an item. This operation must be performed out of a sale.


(You can use the [RC] key instead of this key. See page 41.)

Opening the drawer without a sale

OPERATION		REC	EIPT	
	# _{NS}	#/NS		

Preparing and using department keys


Registering department keys




The following examples show how you can use the department keys in various types of registrations.

Single item sale

Example 1



Example 2 (Subtotal registration and change computation)



Repeat

	Unit price	\$1.50	1 5 0 1	1 DEPT001 1 DEPT001	\$1.50 \$1.50	- Repeat
Item	Quantity	3	1	1 DEPT001 TL	\$1.50 \$4.50	- Repeat
	Dept.	1	1	CASH CG	\$10.00 \$5.50	
Payment	Cash	\$10.00	SUB			
	_		1 0 00 CA/AMT TEND			

RECEIPT

OPERATION

Basic Operations and Setups

Multiplication

OPERATION

RECEIPT

	Unit price	\$1.00
Item	Quantity	12
	Dept.	1
Payment	Cash	\$20.00







Split sales of packaged items

OPERATION

RECEIPT








Department shift

OPERATION

0 00

RECEIPT

	Unit price	\$1.00
Item	Quantity	1
	Dept.	31
Payment	Cash	\$1.00





Department number

OPERATION

RECEIPT

	Unit price	\$13.00
Item	Quantity	1
	Dept.	31
Payment	Cash	\$13.00






CA/AMT TEND

Programming department keys

To program a unit price for each department




^{*} In case of shifting upper department, press | key here.

To program the tax calculation status for each department

Tax calculation status

This specification defines which tax table should be used for automatic tax calculation.




* Press FGM key repeatedly until the status you want to program is appeared on the display.



Appropriate key: In case of shifting department, press key first.

To program high amount limit for each department

Programming procedure




* In case of shifting upper department, press | key here.

Description	Choice	Program code
High amount limit for entering unit price manually.	Significant numbers	\square

Basic Operations and Setups

Registering department keys by programming data



Preset price

OPERATION

RECEIPT

	Unit price	(\$1.00) _{preset}
Item	Quantity	1
	Dept.	2
Payment	Cash	\$1.00





1 DEPT002 \$1.00 TL .00 CASH \$1.00 Department No./ unit price


Preset tax status

OPERATION

RECEIPT








Locking out high amount limitation

OPERATION

RECEIPT

	Unit price	\$1.05
Item	Quantity	1
nem	Dept.	3
	Max.amount	(\$10.00) _{preset}
Payment	Cash	\$2.00





Preparing and using PLUs


This section describes how to prepare and use PLUs.

CAUTION:


Before you use PLUs, you must first program the unit price and tax status.

Programming PLUs

To program a unit price for each PLU



To program tax calculation status for each PLU




* Press RAN key repeatedly until the status you want to program is appeared on the display.




Basic Operations and Setups

Registering PLUs




The following examples show how you can use PLUs in various types of registrations.


PLU single item sale



PLU repeat



PLU multiplication



Split sales of packaged item

OPERATION RECEIPT

	Unit price	(5for\$20.00) _{preset}
Item	Quantity	3
	PLU	28
Payment	Cash	\$15.00



5 00



Open PLU

OPERATION RECEIPT

Item 1	Unit price	\$32.80	3 0 PLU/ S.DEPT	1 PLU0030 1 PLU0031	\$32.80 \$13.00
	Quantity	1	3 2 8 0 PRICE	1 PLU0031	\$13.00 \$58.80
	PLU	30	Unit price	CASH CG	\$60.00 \$1.20
Item 2	Unit price	\$13.00	3 1 PLU/ S.DEPT		
	Quantity	2	1 3 00 PRICE		
	PLU	31	Repeat		
Payment	Cash	\$60.00			
	-		SUB		
			6 0 00 CA/AMT TEND		


Before registering an open PLU, it is necessary to preset it as an open PLU.

Preparing and using discounts

This section describes how to prepare and register discounts.

Programming discounts


To program a rate to the [%-] key



To program the tax calculation status to the %- key

Refer to page 31.

Registering discounts



The following example shows how you can use the [%-] key in various types of registration.

Discount for items and subtotals

OPERATION

RECEIPT

Item 1	Dept. 1	\$5.00	5 00 1	1 DEPT001 1 PLU0016	T1 T2	\$5.00 \$10.00
	Quantity	1	1 6 PLU/ S.DEPT	5% %-	T2	-0.50
	Taxable	(1) _{preset}	%-	ST 3.5%		\$14.50
Item 2	PLU 16	(\$10.00) _{preset}	Applies the preset discount rate to the last item registered.	%- TA1 TX1		-0.51 \$5.00 \$0.20
	Quantity	1	SUB TOTAL	TA2 TX2		\$9.50 \$0.48
	Taxable	(2) _{preset}	3 · 5 %-	TL CASH CG	\$1	4.67 \$15.00 \$0.33
Discount	Rate	(5%) _{preset}	The input value takes priority of the preset value.	CO		φυ. 33
Subtotal discount	Rate	3.5%	SUB TOTAL			
	Taxable	Nontaxable	1 5 00 CA/AMT TEND			
Payment	Cash	\$15.00				

You can manually input rates up to 4 digits long (0.01% to 99.99%).

Taxable status of the |%-| key

- Whenever you perform a discount operation on the last item registered, the tax calculation for discount amount is performed in accordance with the tax status programmed for that item.
- Whenever you perform a discount operation on a subtotal amount, the tax calculation for the subtotal amount is performed in accordance with the tax status programmed for the |%-| key.


Preparing and using reductions

This section describes how to prepare and register reductions.

Programming for reductions

You can use the $\boxed{}$ key to reduce single item or subtotal amounts.


To program preset reduction amount



To program the tax calculation status to the - key

Refer to page 31.

Registering reductions




The following examples show how you can use the — key in various types of registration.

Reduction for items and subtotal

OPERATION

RECEIPT


	Dept. 1	\$5.00
Item 1	Quantity	1
	Taxable	(1) _{preset}
Reduction	Amount	\$0.25
	PLU 45	(\$6.00) _{preset}
Item 2	Quantity	1
	Taxable	(1) _{preset}
Reduction	Amount	(\$0.50) _{preset}
Subtotal Reduction	Amount	\$0.75
	Taxable	(No) _{preset}
Payment	Cash	\$10.00



0.75 TA1 \$10.25 TX1 \$0.41 TL \$9.91 CASH \$10.00 CG \$0.09	TX1 TL CASH	\$10.25 \$0.41 \$9.91 \$10.00
--	-------------------	---

- You can manually input reduction values up to 7 digits long.
- If you want to subtract the reduction amount from the department or PLU totalizer, program "Net totaling."

Registering credit and check payments




The following examples show how to register credits and payments by check.


Check

OPERATION RECEIPT Dept. 1 \$11.00 00 1 1 DEPT001 \$11.00 Reference No. Item #/NS 1234 SUB TOTAL TL 00 Quantity 1 CHECK \$20.00 \$9.00 1234 Number Reference Check \$20.00 Payment

Charge




Credit



Mixed tender (cash and check)

Item Dept. 4 \$55.00 Quantity 1 Payment Check \$30.00 Cash \$25.00 2 5 0 CA/AMT (TEND)				OPERATION	RECEIPT
Quantity 1 SUB CHECK \$30.00 \$25.00 CHK CG \$0.00 CHK \$0.	Itom	Dept. 4	\$55.00		-
Payment South	Item	Quantity	1		CHECK \$30.00
Cash \$25.00 2 5 00 CA/AMT	Dovmant		\$30.00	3 0 00 CHK	CG \$0.00
	rayment	Cash	\$25.00	2 5 00 CA/AMT TEND	

Shifting the taxable status of an item




By pressing "Tax Shift" key, you can shift the taxable status of an item.

Calculation merchandise subtotal

	Dept. 1	\$4.00
Item 1	Quantity	1
	Taxable	(2) _{preset}
	Dept. 2	\$2.00
Item 2	Quantity	1
	Taxable	(No)→1
Item 3	Dept. 3	\$6.00
	Quantity	1
	Taxable	$(1)\rightarrow 1, 2$
	Dept. 4	\$7.00
Item 4	Quantity	1
	Taxable	(2)→No

Cash

\$20.00



OPERATION



OPERATION RECEIPT

1 1 1 1	DEPTOO1 DEPTOO2 DEPTOO3 DEPTOO4 TA1 TX1 TA2 TX2 TL CASH	T2 T1 T12	\$4.00 \$2.00 \$6.00 \$7.00 \$8.00 \$0.32 \$10.00 \$0.50 \$2.00
		\$⊅ I S	


Important!

Payment

To change the tax status of the next item to be registered, be sure to press $\lceil \sqrt{1/52} \rceil$, $\lceil \sqrt{1/52} \rceil$. If the last item registered is programmed as nontaxable, a discount (%- key) operation on this item is always nontaxable.

In this case, you cannot manually change the tax status to Taxable 1 or 2 by pressing the [T/S1], [T/S2] keys.

Registering returned goods in the REG mode



The following example shows how to use the RF key in the REG mode to register goods returned by customers.

OPERATION

RECEIPT

Item 1	Dept. 1	\$2.35
	Quantity	1
Item 2	Dept. 2	\$2.00
Item 2	Quantity	1
Item 3	PLU 1	(\$1.20) _{preset}
	Quantity	1
Returned	Dept. 1	\$2.35
Item 1	Quantity	1
Returned Item 3	PLU 1	(\$1.20) _{preset}
	Quantity	1
Payment	Cash	\$2.00


L
2
/ T





1	DEPT001	\$2.35
1	DEPT002	\$2.00
1	PLU0001	\$1.20
	RF	
1	DEPT001	-2.35
	RF	
1	PLU0001	-1.20
	TL	\$2.00
	CASH	\$2.00

Registering returned goods in the RF mode



The following examples show how to use the RF mode to register goods returned by customers.

OPERATION

RECEIPT

Returned	Dept. 3	\$4.00
Item 1	Quantity	1
Reduction	Amount	\$0.15
Returned Item 2	PLU 2	(\$1.20) _{preset}
	Quantity	1
Discount	Rate	(5%) _{preset}
Payment	Cash	\$4.99




1 DEPT003	\$4.00 -0.15
4 01110000	
1 PLU0002 5%	\$1.20
% –	-0.06
TL	\$4.99
CASH	\$4.99

Important

•To avoid miss registrations in the RF mode, return the mode switch to the former position immediately.

Registering money received on account



The following example shows how to register money received on account. This registration must be performed out of a sale.

OPERATION

RECEIPT


Received amount	\$700.00
-----------------	----------



RC \$700.00

Amount can be up to 8 digits.

Registering money paid out



The following example shows how to register money paid out from the register. This registration must be performed out of a sale.

OPERATION

RECEIPT






\$1.50

Amount can be up to 8 digits.

No sale registration



You can use the following procedure to open the drawer without registering a sale. This operation must be performed out of a sale.


OPERATION

RECEIPT



#/NS

Making corrections in a registration



There are three techniques you can use to make corrections in a registration.

\$To correct an item that you input but not yet registered.

\$To correct the last item you input and registered.


\$To cancel all items in a transaction.

To correct an item you input but not yet registered

OPERATION RECEIPT 2 00 DEPT001 11 DEPT002 \$22.00 C PLU0003 \$1.30 Correction of unit price PLU0015 \$34.30 \$15.00 CASH CHARGE \$19.30 C Correction of quantity 2 00 2 C Correction of PLU No. PLU С Correction of open PLU unit price 5 Enter PLU No. again. PRICE 100 0 00 C Correction of partial tender amount CA/AMT TEND 5 00 CH

To correct an item you input and registered

OPERATION RECEIPT




Basic Operations and Setups

To cancel all items in a transaction

OPERATION

RECEIPT

\$1.00



1 DEPT002 1 DEPT003 \$2.00 \$3.00 1 DEPT004 \$4.00 CANCEL

1 DEPT001

Pressing [SUB] key is necessary to cancel the transaction.





SUB TOTAL

Printing the daily sales reset report

This report shows daily sales totals.

OPERATION





REPORT

- Zero totalled departments/functions (the amount and item numbers are both zero) are not printed.
- These items can be skipped by programming.

Using clerk functions

Enable clerk feature

Please follow the below procedure to enable clerk feature.




Assigning a clerk

You can assign clerks by using clerk number.

Clerk number key

Clerk sign on



• If you do not want the clerk number to be shown on the display, press CLK# before entering the number.

Clerk sign off



• The current clerk is also signed off whenever you set the mode switch to OFF position.

Important!

- The error code "E008" appears on the display whenever you try to perform a registration, a read/ reset operation without signing on.
- The signed on clerk is also identified on the receipt/journal.

Single item cash sales

A department key or PLU programmed with single item sale status finalizes the transaction as soon as it is registered.

The single item sales function can only be used for cash sales.

Example 1

OPERATION

RECEIPT

	Dept. 1	\$1.00
Item	Quantity	1
	Status	S.I.S
Payment	Cash	\$1.00

00 The transaction is immediately finalized.



Example 2

OPERATION

RECEIPT

	Dept. 1	(\$1.00)
Item	Quantity	3
	Status	S.I.S
Payment	Cash	\$3.00



3 DEPT001 \$3.00 . **OO** TL \$3.00


The transaction is immediately finalized.

Example 3

OPERATION

RECEIPT

Item 1	Dept. 3	\$2.00				
	Quantity	1				
	Status	Normal				
	Dept. 1	(\$1.00)				
Item 2	Quantity	1				
	Status	S.I.S				
Payment	Cash	\$3.00				



3

2 00

Because another item is registered before the single item sales department. CA/AMT TEND

1	DEPT003 DEPT001 TL CASH	\$2.00 \$1.00 \$3.00 \$3.00

Currency exchange function

When <CE> key is pressed, a current subtotal including tax is converted directly into foreign currency and the result is displayed, and the subsequent finalization is handled using the foreign currency. The currency exchange function is released by finalizing a transaction, partial tender operation, receipt issuance, or by pressing <SUBTOTAL>.

Before using the currency exchange function, it is necessary to program the conversion rate.

Registering foreign currency

Full amount tender in foreign currency

* Pre-programmed exchange rate: \(\forall 100 = \\$0.9524\)

Important!

Tenders in a foreign currency can be registered using the [AMI] and [CHK] only. Other finalize keys cannot be used.

OPERATION	DISPLAY	RECEIPT
 1 0 00 1	(Displays in \$) (Displays in \$)	1 DEPT001 \$10.00 1 DEPT002 \$20.00 TL \$20.00 CE CASH \$47.62 CG \$17.62
Press CE and SUB without entering a numeric value. This operation converts the subtotal (including tax) dollar value into yen by applying a pre-programmed exchange rate. The result is shown on the display and printed on the receipt/journal by programming.	3. 15 0 (Displays in ¥: 3,150)	
(5,000) EE Enter the amount tendered in yen and press CE. This operation converts the entered yen amount into dollars by applying a preprogrammed exchange rate. The result is shown on the display.	5.000	
Press to finalize the transaction. Note that you do not need to reenter the dollar amount. The register automatically calculates the change amount due in dollars and shows it on the display, receipts and journal.	(Displays in \$)	

Partial tender in a foreign currency

* Pre-programmed exchange rate: ¥ 100 = \$0.9524

Important!

Partial tender in a foreign currency can be registered using and chk only. Other finalization keys cannot be used, but the remaining tender can be finalized using any finalize key.

OPERATION	DISPLAY	RECEIPT
1 0 00 1	the [Displays in \$)	1 DEPT001 \$10.00 1 DEPT002 \$20.00 TL \$30.00
2 0 00 a Enter the next unit price and pretthe applicable department key.		CASH ¥2,000 CASH \$19.05 CHECK \$10.95
Press CE and SUB without e tering a numeric value. This of eration converts the subtotal (if cluding tax) dollar value into y by applying a pre-programmed e change rate. The result is show on the display and printed on the receipt/journal by programming.	(Displays in ¥: 3,150) in- en ex- wn the	
Enter the partial amount tender in yen and press CE. This operation converts the etered yen amount into dollars applying a pre-programmed echange rate. The result is show on the display.	en- by	
Press CA/ANT to specify cash tend for the yen partial tender. No that you do not need to reenter t dollar amount. The register automatically deduct the dollar equivalent of the y amount tendered from the to amount due and shows the amount on the display.	Ote (Displays in \$) cts ren tal	
← Press to finalize the transaction	(Displays in \$)	

Premium

Example

	Dept. 1	\$1.00
Item 1	Quantity	1
	Premium	10%
Item 2	Dept. 1	\$2.00
Item 2	Quantity	3
Subtotal	Premium	(15%)
Payment	Cash	\$8.17

OPERATION



%+

CA/AMT TEND

1 DEPT001 10%	\$1.00
%+	\$0.10
3 DEPT001	\$6.00
ST	\$7.10
15%	·
%+	\$1.07
TL	\$8.17
CASH	\$8.17

RECEIPT

Programming department / PLU descriptors and preset messages in the list

In this chapter, the procedures to choose department / PLU descriptors and preset messages from the preset list are described. Read help receipt, so that you can set the descriptors and messages easily.

How to choose and set the department / PLU descriptors in the list

- 1. Turn to the PGM mode.
- 2. Enter **0 7** and press the HELP key.
- 3. Select the item name and follow these steps in the list.

How to choose and set the preset receipt message and graphic logo in the list

- 1. Turn to the PGM mode.
- 2. Enter 0 8 and press the HELP key. (Programming procedure and Preset message list is issued.)
- 3. Follow these steps in the list.

Preset message and graphic print sample



Character manual input

This chapter shows the procedures to program department / PLU descriptors, store messages, key descriptos, report title, total descriptor (such as gross total, net total...) and clerk name.

The characters you entered by the character keyboard or multi-tapping keyboard, can be programmed.


The "Entering characters" section shows how to enter characters, and the "Programming descriptors and messages by entering characters" shows how to program the entered characters to each memory.

Entering characters

In this section, the method to enter descriptors or messages (characters) to the cash register during programming is

Characters are specified by character keyboard or by multi tapping method. In the first half of this section, the usage of character keyboard is described. In the latter half, inputting method by multi tapping is described.

Using character keyboard



(1) Alphabet keys

Used input to characters.

2 Double size letter key

Specifies that the next characters you input to double size characters. After completion of inputting double size character, press this key for normal size character.

(3) Space key

Set a space by depression.

(4) Clear key

Clears all input characters in the programming.

(5) Delete kev

Clears the last input character, much like a back space key.

Example:

Input " <DBL><A> <DBL><Shift> <l> <e> <Space> <CAPS><J> <Shift><u> <i> <c> <e> . enter

6 Program end key

Terminates the character programming.

(7) Character enter key

Registers the programmed characters.

(8) CAPS key

Pressing this key shifts the character from the lowercase letter to upper case letter.


(9) Shift key

Pressing this key shifts the character from the uppercase letter to lower case letter.

Entering characters by multi tapping

When you enter characters by this method, you need to press each key repeatedly until the desired character appears.

Multi tapping keyboard



1 Alphabet keys

Used input to characters.

Key				T	ext													
7	_7 > x	@ \$ ئ	¥ i	/ % €	: & §	! [(s	? j spa	 , ce)	()	*	#	<u>,</u> +	•	^	; -	〈	= £
8	⊤A å	B æ	C á		Ç	J							À	Ã	Ç	â	ä	à
9	D	Ε	F	d	е	f	9	Ð	É	Ê	Ë	È	ð	é	ê	ë	è	f
4	G	Н	Ι	g	h	i	4	Í	Î	Ϊ	Ì	Ϊ	î	Ì	ĺ	1		
5	J	Κ	L	j	k	Ι	5											
6	_M φ		0 Õ-		n	0	6	Ñ	Ö	Ø	Ó	Ô	Ò	Õ	ñ	ô	ö	Ò
1	Р	Q	R	S	р	q	r	s	1	Þ	þ	ß						
2	Т	U	٧	t	u	٧	2	Ü	Ú	Û	Ù	ü	û	ù	ú	μ		
3	W	Χ	Υ	Z	W	Χ	У	Z	3	Ý	ý	ÿ						
0	0																	
00	(]	Rig	ht	cui	SO	r)												
•	(]	Del	lete	(:														

2 Double size letter key

Specifies that the next characters you input to double size characters. After completion of inputting double size character, press this key for normal size character.

3 Space key

Set a space by depression.

(4) Clear key

Clears all input characters in the programming.

5 Delete key

Clears the last input character, much like a back space key.

6 Program end key

Terminates the character programming.

7 Character enter key

Registers the programmed characters.

8 Right cursor key

Move the cursor to the right by one to enter a character on the same tapping key.

Example:




Programming descriptors and messages by entering characters

The following descriptors and messages can be programmed;

- Report descriptor (such as gross total, net total, cash in drawer...)
- · Grand total
- Special character (such as mode symbol, taxable symbol...)
- Read/reset report title
- Clerk name
- PLU item descriptor


- Messages (Logo, commercial and bottom message)
- Function key descriptor
- Department key descriptor

Programming PLU descriptor



PLU No.	Contents	Initial character	Yours
0001	PLU0001	PLU0001	
0002	PLU0002	PLU0002	
0003	PLU0003	PLU0003	
0004	PLU0004	PLU0004	
0005	PLU0005	PLU0005	
0006	PLU0006	PLU0006	
0007	PLU0007	PLU0007	
0008	PLU0008	PLU0008	
0009	PLU0009	PLU0009	
0010	PLU0010	PLU0010	
0011	PLU0011	PLU0011	
0012	PLU0012	PLU0012	
0013	PLU0013	PLU0013	
0014	PLU0014	PLU0014	
0015	PLU0015	PLU0015	
0016	PLU0016	PLU0016	
0017	PLU0017	PLU0017	
0018	PLU0018	PLU0018	
0019	PLU0019	PLU0019	
0020	PLU0020	PLU0020	
0021	PLU0021	PLU0021	
0022	PLU0022	PLU0022	
0023	PLU0023	PLU0023	
0024	PLU0024	PLU0024	
0025	PLU0025	PLU0025	
0026	PLU0026	PLU0026	
0027	PLU0027	PLU0027	
0028	PLU0028	PLU0028	
0029	PLU0029	PLU0029	
0030	DI 110030	PL I/0030	

Programming department / function key descriptor



^{*1} Appropriate key: In case of shifting department, press <DEPT SHIFT> key first.


Function key

Contents	Initial character	Yours
Cash/amount tendered	CASH	
Charge	CHARGE	
Check	CHECK	
Credit	CREDIT	
Received on account	RC	
Paid out	PD	
Minus	-	
Discount	%-	
Premium	%+	
Receipt on/off	RCT ON/OFF	
Post receipt	RCT	
Refund	RF	
Error correct/Cancel	CORR	
Sign off	SIGN-OFF	
Open	OPEN	
Department shift	SHIFT/No	
Multiplication/For/Date time	QT	
Tax shift 1	T/S1	
Tax shift 2	T/S2	
Non-add / No sale	#/NS	
Currency exchange	CE	

Department key

Contents	Initial character	Yours
Department 001	DEPT001	
Department 002	DEPT002	
Department 003	DEPT003	
Department 004	DEPT004	
Department 005	DEPT005	
Department 006	DEPT006	
Department 007	DEPTO07	

Programming message



Receipt message

Refer to "(message control)" on page 64.

Memory No.	Contents	Initial character	Yours
01	1st line of logo message	YOUR RECEIPT	
02	2nd line of logo message	THANK YOU	
03	3rd line of logo message	CALL AGAIN	
04	4th line of logo message		
05	1st line of commercial message		
06	2nd line of commercial message		
07	3rd line of commercial message		
08	4th line of commercial message		
09	1st line of bottom message		
10	2nd line of bottom message		
11	3rd line of bottom message		
12	4th line of bottom message		
:	:		
25	(not used)	DUPLICATE RECEIPT	
:	:		
40	Australian GST message 1st. line	TAX INVOICE	
41	Australian GST message 2nd. line	* INDICATES	
42	Australian GST message 3rd. line	TAXABLE SUPPLY	


Programming Clerk name



Clerk name

Clerk No.	Contents	Initial character	Yours
01	Clerk 01	C01	
02	Clerk 02	C02	
03	Clerk 03	C03	
04	Clerk 04	C04	
		205	

Programming other descriptors



Report descriptor

Memory	Program	Contents	Initial character	Yours
No.	code	00	2222242 222424222	10015
01		Gross total	GROSS	
02		Net total	NET	
03		Cash in drawer	CAID	
04		Charge in drawer	CHID	
05		Check in drawer	CKID	
06		Credit 1 in drawer	CRID(1)	
07		Credit 2 in drawer	CRID(2)	
08		Credit 3 in drawer	CRID(3)	
09		Credit 4 in drawer	CRID(4)	
10		Cash in drawer for sub currency	CAID2	
11		Charge in drawer for sub currency	CHID2	
12		Check in drawer for sub currency	CKID2	
17		Refund mode total	RF	
18		Customer count	CUST	
19		Average sales per customer	AVER	
20		Clerk commision 1 total	C-1	
21	01	Clerk commision 2 total	C-2	
22		Foreign currency cash in drawer	CECA1	
23		Foreign currency check in drawer	CECK1	
26		Reduction	DC	
27		Coupon	COUPON	
28		Item return	REF	
29		Rounding for sub currency	ROUND	
30		Rounding	ROUND	
31		Cancellation	CANCEL	
33		Taxable amount 1	TA1	
34		Tax 1	TX1	
35		Taxable amount 2	TA2	
36		Tax 2	TX2	
37		Taxable amount 3	TA3	
38		Tax 3	TX3	
39		Taxable amount 4	TA4	
40		Tax 4	TX4	
41		Non taxable amount	NON TAX	

Grand total, special character

Memory No.	Program code	Contents Initial character	Yours
01		main currency symbol (2), @ (2), No. (2), split pricing (2), not used (4), sub currency symbol (2)	\$@ Nq/. * *
02		No. of item sold (2), No. of customer (2), not used (6), multiplication display (2)	NaCT @LB *QT
03		multiplication (6) not used (6)	
04		taxable symbol 1 (3 each) for tax 1, tax 2, tax 3, tax 4	Ti1::Ti2::Ti3::Ti4::Ti5::
06		taxable symbol 3 (3 each) for tax 1/2, tax 1/3, not used, not used, tax 2/3	T,1,2T,1,3T,1,4 , , , T,2,3
08		foreign currency (2 each), not used (8)	* * *
09	23	mode symbol 1 (4 each) REG1/2, RF, not used	REG RER
10		mode symbol 2 (4 each) PGM, Daily X, Daily Z, Periodic	P'\\X \ \ Z \ \ XZ \
11		mode symbol 3 (4 each) not used, PGM read	TRG PGMX
12		decimal: amount/q'ty, separator (main/sub) (1 each), not used (3), square (7)	,,. X
13		A.M., P.M. (3 each), ST displayed on the dot display (2)	AM PM ST !!!!!
16		display subtotal symbol (ST key) (16)	STILLILLILLI
17		subtotal discount / premium symbol (16)	ST
18		post receipt total symbol (16)	TIL I I I I I I I I I I I I I I I I I I
19		change symbol (16)	CG
01	20	Grand total (16)	GT,


Report title

Memory No.	Program code	Contents	Initial character			,	You	urs		
01		Fixed total report title	FIX							
02		Transaction key report title	TRANS							
03		PLU sales report title	PLU							
04		Department sales report title	DEPT							
05	24	Group sales report title	GROUP							
06		Clerk sales report title	CASHIER							
08		Hourly sales report title	HOURLY							
09		Monthly sales report title	MONTHLY							
16		Financial report title	FLASH							

Machine feature program

General control program

Programming procedure



Program data (by address code)

Address code 02 (machine number)

Description	Choice	Program code	Initial value
Machine number	Significant numbers	D_4 D_3 D_2 D_1	0 0 0 0 D ₄ D ₃ D ₂ D ₁

Address code 03 (consecutive number)

Description	Choice	Program code	Initial value
Reset consecutive number after daily reset report is issued.	Yes = 0 No = 1	\mathbf{D}_8	$egin{bmatrix} oldsymbol{0} \ D_8 \ \end{pmatrix}$
Always "00000000"		$ \begin{array}{c c} 0 \sim 0 \\ D_7 \sim D_1 \end{array} $	$ \begin{array}{c c} 0 \sim 0 \\ D_7 \sim D_1 \end{array} $

Address code 04 (tax system)

Description	Choice	Program code	Initial value
Tax system U.S. tax system = 1, Canadian tax system = 2	Significant number	D_9	(U.S.) (Canada) D ₉
Always "00000000"		0 ~ 0 D ₈ ~ D ₁	0 ~ 0 D ₈ ~ D ₁

Address code 05 (print control for receipt)

Description		Choice	Program code	Initial value
Print total line during finalization.	a	Yes = 0 No = 1		0
Time system: ① 24 hour system, ② 12 hour system	b	① = 0 ② = 2	$\stackrel{(\overline{a+b})}{D_{10}}$	(a+b) D ₁₀
Buffered receipt print *1		No = 0 Yes = 2	D_{q}	\mathbf{O} \mathbf{D}_{9}
Skip item lines on journal. (journal skip)		No = 0 Yes = 1	D_{s}	\mathbf{O} \mathbf{D}_8
Always "000"			$ \begin{array}{c c} 0 & 0 & 0 \\ D_7 & D_6 & D_6 \end{array} $	$\begin{array}{c c} 0 & 0 & 0 \\ D_7 & D_6 & D_5 \end{array}$
Print number of item sold. (item counter)	a	No = 0 Yes = 1		0
Print tax symbols.	b	Yes = 0 No = 2	(a+b) D ₄	$\stackrel{(\overline{a+b})}{D_4}$
Always "00"			0 0 D ₃ D ₂	0 0 D ₃ D ₂
Always "0".	·		\mathbf{O}	O D ₁

^{*1:} Select "Yes" if you want to print receipts with watermarks.

Address code 06 (calculation & operation control)

Description		Choice	Program code	Initial value
Follow the taxable status and commission status of previous item when +/-operation is performed.	a	Yes = 0 $No = 1$		0
Force a money declaration before read/reset operation.	b	No = 0 Yes = 4	(a+b) D ₁₀	$\overset{(\overline{a}+\overline{b})}{D_{10}}$
Force to press SUB total before finalization	a	No = 0 Yes = 1		
Allow credit balance while finalization.	b	Yes = 0 No = 2	(a+b+c)	(a+b+c)
Allow multiple refund operation.	с	Yes = 0 No = 4	D_{9}	D_{9}
Affect the result of +/-, %+/%- to the item. (Net totalling)		No = 0 Yes = 1	D_8	$egin{bmatrix} oldsymbol{0} \ D_8 \ \end{pmatrix}$
Include commission in net total.		Yes = 0 $No = 2$	D_7	\mathbf{O} D_{7}
Clear the key buffer when a receipt is issued. (REG mode only)	a	No = 0 Yes = 1		
Sounds key catch tone.	b	Yes = 0 No = 2	(a+b+c)	(a+b+c)
Allow to issue post receipt, even if the original one is issued.	С	No = 0 Yes = 4	D_6	D_6
Always "00"			0 0 D ₅ D ₄	0 0 D ₅ D ₄
Always "0"			O D ₃	$\overline{\mathrm{D}_{3}}$
Use <00> key as <000> key.		<00> = 0 <000> = 4	D_2	0 D ₂
Always "0".			0 D ₁	0 D ₁

Address code 08 (print control for fixed total report)

Description		Choice	Program code	Initial value
Print gross sales total on fixed total report (GROSS)	a	Yes = 0 $No = 1$		
Print net sales total on fixed total report (NET)	b	Yes = 0 No = 2	(a+b+c)	(a+b+c)
Print cash in drawer total on fixed total report (CAID)	с	Yes = 0 No = 4	D_{10}	D ₁₀
Print charge in drawer total on fixed total report (CHID)		Yes = 0 $No = 2$	D_{q}	0 D ₉
Print check in drawer total on fixed total report (CKID)	a	Yes = 0 $No = 1$		0
Print credit in drawer total on fixed total report (CRID(1)~(4))	b	Yes = 0 $No = 4$	(a+b) D ₈	(a+b) D ₈
Always "0"			0 D ₇	0 D ₂
Print RF mode total on fixed total report (RF)		Yes = 0 $No = 4$	D_6	D_6
Print the net number of customers on fixed total report (CUST)	a	Yes = 0 $No = 1$		2
Print the average sales per customer on fixed total report (AVER)	b	Yes = 0 No = 2	$D_{5}^{(\overline{a+b})}$	$(\overline{a+b})$ D_5
Always "0"			0 D ₄	0 D ₄
Print commission 1 total on fixed total report (C-1)	a	Yes = 0 $No = 1$		
Print commission 2 total on fixed total report (C-2)	b	Yes = 0 No = 2	(a+b+c) D ₃	(a+b+c) D ₃
Print foreign currency cash in drawer and check in drawer totals on fixed total report (CECA1 ~ 2, CECK1 ~ 2)	c	Yes = 0 No = 4	3	3
Print <minus>, <coupon>, <%-> and mix & match operation net total on fixed total report (DC)</coupon></minus>	a	Yes = 0 No = 1	(a+b+c)	(a+b+c)
Print <refund> and <void> operation net total on fixed total report (REF)</void></refund>	b	Yes = 0 No = 2	D_2	D_2
Print nontaxable totals on fixed total report (NON TAX)	a	Yes = 0 No = 1		
Print rounding totals on fixed total report (ROUND)	b	Yes = 0 No = 2	(a+b+c)	(a+b+c)
Print cancellation total on fixed total report (CANCEL)	С	Yes = 0 $No = 4$	D ₁	D ₁

Address code 10 (print control for taxable amount)

Description		Choice	Program code	Initial value
Print taxable amount 1 on receipt/journal.	a	Yes = 0 No = 1		
Print taxable amount 2 on receipt/journal.	b	Yes = 0 No = 2	(a+b+c)	(a+b+c)
Print taxable amount 3 on receipt/journal.	c	Yes = 0 No = 4	D ₁₀	D ₁₀
Print taxable amount 4 on receipt/journal.		Yes = 0 No = 1	D_{q}	0 D ₉
Always "00000000"			0 ~ 0 D ₈ ~ D ₁	0 ~ 0 D ₈ ~ D ₁

Address code 14 (currency exchange control)

Description		Choice	Program code	Initial value
Monetary mode of CECA1 and CECK1 in fixed total report:		Significant number (0 ~ 9)	$\overline{\mathrm{D}_8}$	$egin{bmatrix} oldsymbol{0} \ D_8 \ \end{pmatrix}$
Decimal for CECA1 and CECK1 in fixed total report: ① Period = 0, ② Comma = 1	a (1) = 0 (2) = 1			0
Separator for CECA1 and CECK1 in fixed total report: ① Comma = 0, ② Period = 1	b	① = 0 ② = 4	(a+b) D ₇	(a+b) D ₇
Monetary mode of CECA2 and CECK2 in fixed total report:		Significant number (0 ~ 9)	$\overline{\mathbb{D}}_{6}$	$oxed{0}$ $oxed{D}_6$
Decimal for CECA2 and CECK2 in fixed total report: ① Period = 0, ② Comma = 1	a	$ \begin{array}{c} \boxed{1} = 0 \\ \boxed{2} = 1 \end{array} $		0
Separator for CECA2 and CECK2 in fixed total report: ① Comma = 0, ② Period = 1	b	① = 0 ② = 4	(a+b) D ₅	$ \begin{array}{c} (\overline{a+b}) \\ D_5 \end{array} $
Always "0000"			0 0 0 0 D ₄ D ₃ D ₂ D ₁	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$

Address code 15 (print control for reports)

Description		Choice	Program code	Initial value
Zero skip department report.	a	Yes = 0 $No = 1$		0
Zero skip clerk report.	b	Yes = 0 No = 2	$\stackrel{(\overline{a+b})}{D_{_{10}}}$	D_{10}
Zero skip transaction report.	a	Yes = 0 No = 1		
Zero skip PLU report.	b	Yes = 0 $No = 2$	(a+b+c) D ₉	(a+b+c) D ₉
Zero skip hourly report.	c	Yes = 0 $No = 4$	D_9	D_9
Zero skip group report.		Yes = 0 $No = 1$	D_8	\mathbf{O} \mathbf{D}_8
Always "00"			$\begin{bmatrix} 0 & 0 \\ \mathbf{D}_7 & \mathbf{D}_6 \end{bmatrix}$	$\begin{bmatrix} 0 & 0 \\ \mathbf{D}_7 & \mathbf{D}_6 \end{bmatrix}$
Print PLU number on the PLU report.		No = 0 Yes = 4	D_5	0 D ₅
Print sales ratio.	a	No = 0 Yes = 1		0
Issue double Z report.	b	No = 0 Yes = 2	$\overset{(\overline{a+b})}{D_4}$	$\overset{(\overline{a+b})}{\mathrm{D_4}}$
Always "000"			$ \begin{array}{c c} \hline 0 & 0 & 0 \\ D_3 & D_2 & D_1 \end{array} $	$\begin{bmatrix} 0 & 0 & 0 \\ D_3 & D_2 & D_1 \end{bmatrix}$

Address code 16 (print control for grand total)

Description	Choice	Program code	Initial value
Print consecutive number range of the day on daily fixed total report.	No = 0 Yes = 1	$\overline{\mathbb{D}_7}$	$egin{bmatrix} oldsymbol{0} \ D_{7} \ \end{array}$
Always "00000"		0 ~ 0 D ₆ ~ D ₂	0 ~ 0 D ₆ ~ D ₂
Print grand total on daily sales reset report.	Yes = 0 No = 1	D_1	\mathbf{O}

Address code 17 (print control)

Description		Choice	Program code	Initial value
Print date on journal.	a	Yes = 0 $No = 2$		0
Print consecutive number on receipt/journal.	b	Yes = 0 No = 4	D_4	$\overset{(a+b)}{\mathrm{D}_4}$
Print time on receipt.	a	Yes = 0 No = 1		0
Print time on journal.	b	Yes = 0 $No = 2$	(a+b) D ₃	(a+b) D ₃
Always "00"			$\begin{bmatrix} 0 & 0 \\ D_2 & D_1 \end{bmatrix}$	$\begin{bmatrix} 0 & 0 \\ D_2 & D_1 \end{bmatrix}$

Address code 19 (receipt control)

Description	Choice	Program code	Initial value
Print receipt in double-height characters.	No = 0 Yes = 1	$\overline{\mathrm{D}_{7}}$	\mathbf{O} \mathbf{D}_{7}
Always "000000"		$ \begin{array}{c c} 0 & \sim 0 \\ D_6 & \sim D_1 \end{array} $	$ \begin{array}{c c} 0 \sim 0 \\ D_6 \sim D_1 \end{array} $

Address code 21 (message control)

Description		Choice	Program code	Initial value
Print graphic type logo. (If select "No", character type logo is printed.)	a	No = 0 Yes = 2		(a+b) D ₁₀
Print watermark on receipt.	b	Yes = 0 No = 4	(a+b) D ₁₀	
Always "000"			$\begin{array}{c c} \textbf{0} & \textbf{0} & \textbf{0} \\ D_9 & D_8 & D_7 \end{array}$	0 0 0 D ₉ D ₈ D ₇
Print commercial message on receipts in REG/RF mode.	a	No = 0 Yes = 1		(a+b) D ₆
Print bottom message on receipts in REG/RF mode.	b	No = 0 Yes = 2	(a+b) D ₆	
Always "0000"			0 0 0 0 D ₅ D ₄ D ₃ D ₂	0 0 0 0 D ₅ D ₄ D ₃ D ₂
Always "0"			0	0

Address code 27 (clerk control)

Description	Choice	Program code	Initial value
Enable clerk function.	No = 0 Yes = 4	D_9	$egin{bmatrix} oldsymbol{0} \ D_{9} \ \end{array}$
Always "00000000"		0 ~ 0 D ₈ ~ D ₁	$\begin{bmatrix} 0 & \sim & 0 \\ D_8 & \sim & D_1 \end{bmatrix}$

Address code 30 (thermal printer control)

Description		Choice	Program code	Initial value
Print preset receipt message and graphic	a	No = 0 Yes = 1		0
Print preset receipt message and graphic: ① at the bottom of the receipt / ② at the top of the receipt	b (1) = 0 (2) = 2		(a+b) D ₅	(a+b) D ₅
Journal compressed print (print by half height characters)		Yes = 0 No = 1	D_4	O D ₄
Always "000"			$\begin{array}{c c} \textbf{0} & \textbf{0} & \textbf{0} \\ D_3 & D_2 & D_1 \end{array}$	$ \begin{array}{c c} \hline 0 & 0 & 0 \\ D_3 & D_2 & D_1 \end{array} $


Address code 34 (backlight control)

Description	Choice	Program code	Initial value
Backlight	Available = 0 Not available = 1	$oxdot D_4$	0 D ₄
Always "000"		$\begin{bmatrix} 0 & 0 & 0 \\ \mathbf{D}_3 & \mathbf{D}_2 & \mathbf{D}_1 \end{bmatrix}$	$\begin{bmatrix} 0 & 0 & 0 \\ D_3 & D_2 & D_1 \end{bmatrix}$


Key function program

Department key/PLU program (Batch feature programming)

Programming procedure



*: In case of shifting department, press <DEPT SHIFT> key first.




Program data


Description		Choice	Program code	Initial value
Single item control: Normal receipt = 0, Single item receipt = 3		Significant number	D_{12}	$egin{bmatrix} oldsymbol{0} \ D_{12} \ \end{pmatrix}$
Always "0"			O D ₁₁	0 D ₁₁
Always "0"			O D ₁₀	0 D ₁₀
Always "0"			$\overline{0}$ $\overline{\mathbf{D}}_{9}$	\mathbf{O} D_9
Taxable status: See page 68.			D_8 D_7	D_8 D_7
Enable 0 unit price.	a	No = 0 $Yes = 1$		
Enable negative price.	b	No = 0 Yes = 2	(a+b+c) D ₆	$\begin{bmatrix} 0 \\ (a+b+c) \\ D_6 \end{bmatrix}$
Hash	с	No = 0 Yes = 4	D_6	D ₆
Always "0"			0 D ₅	0 D ₅
Low digit limitation (LDL) for manually entered unit price.		Significant number	$oxdot D_4$	0 D ₄
Open PLU (only for PLU)		No = 0 Yes = 4	D_3	D_3
Commission 1	a	No = 0 Yes = 1		0
Commission 2	b	No = 0 Yes = 2	(a+b) D ₂	$\overset{(\overline{a+b})}{D_2}$
Always "0"			O D ₁	0 D ₁

Department key/PLU program (Individual feature programming)

Programming procedure



*: In case of shifting department, press <DEPT SHIFT> key first.



Program data (by address code)

Address code 11 (link)

Description	Choice	Program code
Link group record number: (000 ~ 999)	Significant numbers	$\begin{array}{c c} & \\ \hline D_7 & D_6 & D_5 \end{array}$
Always "0"		0 D ₄
Link department record number: (000 ~ 999) (only for PLU)	Significant numbers	$\begin{array}{c c} \hline \\ D_3 & D_2 & D_1 \\ \hline \end{array}$

Address code 15 (high amount limit)

Description	Choice	Program code
High amount limit for entering unit price manually.	Significant numbers	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$

Other address code

Address code	Description	Choice	Program code	
18	Single item control: Normal receipt = 0, Single item receipt = 3		Significant number	
03	Taxable status: See page 68.		Significant numbers	D_2 D_1
	Enable 0 unit price.	a	No = 0 Yes = 1	
05	Enable negative price.	b	No = 0 Yes = 2	(a+b+c)
	Hash	с	No = 0 Yes = 4	(a.e.e)
07	Low digit limitation (LDL) for manually entered unit price.		Significant number	
04	Open PLU (Only for PLU)		No = 0 Yes = 4	
09	Commission 1	a	No = 0 Yes = 1	
09	Commission 2	b	No = 0 Yes = 2	(a+b)

Taxable status

for the U.S.


Always "0"			$oldsymbol{O}_{B}$
Taxable 1 status	a	No = 0 Yes = 1	
Taxable 2 status	b	No = 0 Yes = 2	(a+b+c) D ₇
Taxable 3 status	С	No = 0 Yes = 4	,

for Canada

Always "0"				0 D ₈
Non tax = 0 Taxable 1 = 1 Taxable 2 = 2	Taxable $3 = 3$ Taxable $4 = 4$ Taxable $1 & 2 = 5$	Taxable 1 & $3 = 6$ Taxable 1 & $4 = 7$	Significant number	D_{7}

Transaction key program

Programming procedure



Program data

<CASH>, <CHARGE>, <CHECK>

Description		Choice	Program code
Prohibit entry of a partial payment	a	No = 0 Yes = 1	
Prohibit the entry of the amount tendered.	b	No = 0 Yes = 2	(a+b+c)
Force entry of the amount tendered.	с	No = 0 Yes = 4	D_{7}
Print VAT breakdown. *1		No = 0 Yes = 1	$\overline{\mathrm{D}_{_{6}}}$
Always "0"			D_{5}
High amount limit specification for subtotal and tendering amounts.		Maximum value $(0 \sim 9)$ Number of zeros $(0 \sim 9)$	D_4 D_3
High amount limit specification for change amount due.		Maximum value $(0 \sim 9)$ Number of zeros $(0 \sim 9)$	D_2 D_1

^{*1} This is valid option for Single item or Currency exchange (include partial tender) as well.

<RECEIVED ON ACCOUNT>, <PAID OUT>

Description	Choice	Program code
High amount limit specification for entering amounts	Maximum value $(0 \sim 9)$ Number of zeros $(0 \sim 9)$	D_4 D_3
Always "00"		$\begin{bmatrix} 0 & 0 \\ \mathbf{D}_2 & \mathbf{D}_1 \end{bmatrix}$

<REDUCTION (MINUS)>

Description		Choice	Program code
Taxable status: See page 68.			D_8 D_7
Allow credit balance. (-, CPN only)		No = 0 Yes = 1	D_6
Always "00"		No = 0 Yes = 2	0 0 D ₅ D ₄
High digit limitation (HDL) for manually entered unit price ("9" means NOT allow manual entry.)			D_3
Commission 1	a	Significant number	
Commission 2	b	No = 0 Yes = 1	(a+b) D ₂
Always "0"		No = 0 Yes = 2	0 D ₁

<PREMIUM (%+)>, <DISCOUNT (%-)>

Description		Choice	Program code
Taxable status: See page 68.			$egin{bmatrix} oxedsymbol{igspace} oxedsymbol{ox} oxedsymbol{ox} oxedsymbol{ox} oxedsymbol{ox}_7 \end{pmatrix}$
Prohibit manual rate override.		No = 0 Yes = 2	D_6
Rounding: Round off = 0, cut off = 1, round up = 2		Significant number	D_{5}
Always "00"			$\begin{bmatrix} 0 & 0 \\ \mathbf{D}_4 & \mathbf{D}_3 \end{bmatrix}$
Commission 1	a	No = 0 Yes = 1	
Commission 2	b	No = 0 Yes = 2	(a+b) D ₂
Always "0"			$egin{bmatrix} oldsymbol{0} \ D_1 \ \end{array}$

<NON-ADD (#)/NO SALE>

Description	Choice	Program code
Allow mode change or clerk change after non-add registration as first transaction. (only for non-add function)	Yes = 0 No = 1	D_7
Always "0000"		0 0 0 0 D ₆ D ₅ D ₄ D ₃
Always "00"		$\begin{bmatrix} 0 & 0 \\ \mathrm{D}_2 \mathrm{D}_1 \end{bmatrix}$

<SUBTOTAL>, <MERCHANDISE SUBTOTAL>

Description	Choice	Program code
Print when key is pressed.	No = 0 Yes = 4	$\overline{\mathrm{D}_{6}}$
Always "00000"		0 0 0 0 0 D ₅ D ₄ D ₃ D ₂ D ₁

<CURRENCY EXCHANGE>

Description		Choice	Program code
Define amount symbol. (0, 1 ~ 2) ("0" means local currency symbol.)		Significant number	\mathbf{D}_{7}
Define foreign currency totalizer. $(0, 1 \sim 2)$ ("0" treats as "1".)		Significant number	$\overline{\mathbb{D}}_{6}$
Rounding: Round off = 0, cut off = 1, round up = 2		Significant number	D_{5}
Always "0"			0 D ₄
Monetary mode $(0 \sim 9)$: $\square \square \square$		Significant number	D_3
Monetary symbol for decimal	a	Decimal = 0 Comma = 1	
Monetary symbol for separator	b	Comma = 0 Decimal = 4	(a+b) D ₂
Always "0"			0 D ₁

<MULTIPLICATION / FOR>

Description	Choice	Program code
Multiplication procedure: (<x> only) ① Quantity × Amount, ② Amount × Quantity</x>	① = 0 ② = 1	D_6
Rounding: Round off = 0, cut off = 1, round up = 2	Significant number	D_{5}
Always "0000"		0 0 0 0 D ₄ D ₃ D ₂ D ₁

<TAX SHIFT>


Description	Choice	Program code
Taxable status (00, 01 ~ 04) ("00" means taxable 1.)	Significant numbers	$egin{array}{ c c c c c c c c c c c c c c c c c c c$
Always "000000"		$\begin{array}{c ccccccccccccccccccccccccccccccccccc$

<CREDIT>

Description		Choice	Program code
Prohibit entry of a partial payment	a	No = 0 Yes = 1	
Prohibit the entry of the amount tendered.	b	No = 0 Yes = 2	(a+b+c) D ₇
Force entry of the amount tendered.	с	No = 0 Yes = 4	
Print VAT breakdown.		No = 0 Yes = 1	D_6
Always "0"			0 D _s
High amount limit specification for subtotal and tendering amounts.		Maximum value (0 ~ 9)	
Then unloans that specification for subtotal and tendoring unloans.		Number of zeros (0 ~ 9)	D_4 D_3
Always "0"			0 D,
Specify credit in drawer total in the fixed totalizer.		Significant number (0 ~ 4)	D_1

Clerk program

Clerk number, check number programming



Program Data

Description	Choice	Program code
Clerk secret number	Significant numbers	$egin{array}{ c c c c c c c c c c c c c c c c c c c$

Clerk other programming

Programming procedure (individual) To a new (not sequential) clerk To the next clerk **PGM** SUB TOTAL CA/AMT TEND Record No. Mode switch

Address code

Program data

Program data

Address code 67 (Clerk control)

Description	Choice	Program code
Training clerk	No = 0 Yes = 1	$\overline{\mathbb{D}}_{6}$
Always "00000"		0 ~ 0 D ₅ ~ D ₁

Address code 68 (Commission rate)

Description	Choice	Program code
Commission rate 1 (integer: 00 ~ 99)	Significant numbers	$egin{array}{cccc} oxed{D_8} & oxed{D_7} \end{array}$
Commission rate 1 (decimal: 00 ~ 99)	Significant numbers	D_6 D_5
Commission rate 2 (integer: 00 ~ 99)	Significant numbers	D_4 D_3
Commission rate 2 (decimal: 00 ~ 99)	Significant numbers	D_2 D_1

Printing read/reset reports

Daily sales read report ("X" mode)

You can print read reports at any time during the business day without affecting the data stored in the cash register's memory.

• Daily sales reset report ("Z" mode)

You should print reset reports at the end of the business day.

Important!


- The reset operation issues a report and also clears all sales data from the cash register's memory.
- Be sure to perform the reset operations at the end of each business day. Otherwise, you will not be able to distinguish between the sales data for different dates.


To print the individual department, PLU read report

This report shows sales for specific departments or PLUs.


OPERATION DISPLAY

1. Turn to X mode.





- 2. Specify a department / PLU.
 - Specifying a department 1, 2, DEPT# 3... • Specifying a PLU 1 PLU, 1 0 PLU ...
- 3. Press <ST> to exit this report.




To print daily read reports

You can select the appropriate report shown in the display.

OPERATION DISPLAY

1. Turn to X mode.



2. Select report you want to get by the <RC> key.





- 3. Press <CASH> to print report. *1
- *1 If money declaration is necessary, count how much cash is in the drawer and input this amount (up to 10 digits) and press <#/NS> key.
 - The cash register will automatically compare the input with the cash in drawer in the memory and print the difference between these two amounts.

Note that if money declaration is required by programming, you cannot skip this procedure.


Advanced Operations and Setups

To print daily reset reports

You can select the appropriate report shown in the display.

OPERATION DISPLAY

1. Turn to Z mode.



NEXT:RC DAILY Z

2. Select report you want to get by the <RC> key.




- 3. Press <CASH> to print report. *1
- *1 If money declaration is necessary, count how much cash is in the drawer and input this amount (up to 10 digits) and press <#/NS> key.

The cash register will automatically compare the input with the cash in drawer in the memory and print the difference between these two amounts.

Note that if money declaration is required by programming, you cannot skip this procedure.

Read / reset report sample

Daily report




Zero totalled departments/functions (the amount and item numbers are both zero) are not printed.


These items can be skipped by programming.

Advanced Operations and Setups


Flash report




PLU report




Hourly report



Monthly report



Group report



Advanced Operations and Setups

Periodic sales read report ("X2" mode)

You can print read reports at any time during the business day without affecting the data stored in the cash register's memory.

Periodic sales reset report ("Z2" mode)


You should print reset reports at the end of the business day.

To print the periodic 1/2 sales read/reset reports

These reports show sales breakdowns of sales by any two kinds of period you want.

OPERATION DISPLAY

1. Turn to X2/Z2 mode.






2. Select report you want to get by the <RC> key.



3. Press <CASH> to print report.



Taxable 2 amount *2

Tax 2 amount *

\$2,172.96 \$217.33

TA2 TX2

Zero totalled departments/functions (the amount and item numbers are both zero) are not printed.


These items can be skipped by programming.

Reading the cash register's program

To print unit price/rate program (except PLU)

OPERATION REPORT


- 1. Turn to PGM mode.
- 2. Enter <1> and press <ST> key.
- 3. Press <ST> key.




To print key descriptor, name, message program (except PLU)

OPERATION REPORT

- 1. Turn to PGM mode.
- 2. Enter <2> and press <ST> key.
- 3. Press $\langle ST \rangle$ key.







To print the machine program (except PLU)

OPERATION REPORT

- 1. Turn to PGM mode.
- 2. Enter <3> and press <ST> key.
- 3. Press <ST> key.






Advanced Operations and Setups

To print the PLU unit price

OPERATION REPORT


- 1. Turn to PGM mode.
- 2. Enter <6> and press <ST> key.
- 3. Enter <104> and press <ST> key.
- 4. Enter <start rec-#> and <CA> key.
- 5. Enter <end rec-#> and <CA> key.



To print the PLU descriptor

OPERATION REPORT


- 1. Turn to PGM mode.
- 2. Enter <6> and press <ST> key.
- 3. Enter <204> and press <ST> key.
- 4. Enter <start rec-#> and <CA> key.
- 5. Enter <end rec-#> and <CA> key.



To print the PLU program

OPERATION REPORT

- 1. Turn to PGM mode.
- 2. Enter <6> and press <ST> key.
- 3. Enter <304> and press <ST> key.
- 4. Enter <start rec-#> and <CA> key.
- 5. Enter <end rec-#> and <CA> key.



This section describes what to do when you have problems with operation.

When an error occurs

Errors are indicated by an error codes. When this happens, you can usually find out what the problem is as illustrated below.

Press [C] and check the appropriate section of this manual for the operation you want to perform.


Error code	Message	Meaning	Action	
E001	Wrong mode	Mode switch position changed before finalization.	Return the mode switch to its original setting and finalize the operation.	
E003	Wrong operator	The signed on clerk differs from the clerk performed the tracking check registration.	Input correct check number or assign the proper clerk number.	
	Error INIT/FC	Initialization or unit lock clear operation in progress.	Complete operation.	
	Please sign on	Registration without entering a clerk number.	Enter a clerk number.	
E010	Close the drawer	The drawer is left open longer than the program time (drawer open alarm).	Close the drawer.	
E011	Close the drawer	Attempt to register while the cash drawer is open.	Shut the cash drawer.	
E016	Change back to REG	Two consecutive transactions attempted in the refund	Switch to another mode and then back to the RF mode	
	mode	mode.	for the next transaction.	
E017	Enter CHK/TBL number	Attempt made to register an item without inputting a check number.	Input a check number.	
E018	Enter Table number	Attempt made to register an item without inputting a table number.	Input a table number.	
E019	Enter number of customers	Finalize operation attempted without entering the number of customer.	Enter the number of customer.	
	No DEPT Link	No department linked PLU is registered.	Correct the program.	
E026	Enter condiment/	No condiment/preparation PLU is registered.	Register condiment/preparation PLU.	
	preparation PLU			
E029	In the tender operation	Item registration is prohibited, while partial tender.	Finalize the transaction.	
E031	Press ST key	Finalization of a transaction attempted without confirming the subtotal.	Press <subtotal>.</subtotal>	
E033	Enter tendered amount	Finalize operation attempted without entering amount tender.	Enter the amount tendered.	
E035	Change amount exceeds limit	Change amount exceeds preset limit.	Input amount tendered again.	
E036	Remove money from the drawer	: Contents of the drawer exceed programmed limit.	Perform paidout operation.	
E037	Digit or amount limitation over	High amount lock out/low digit lock out error	Enter correct amount.	
E038	Perform money declaration	Read/reset operation without declaring cash in drawer. This error appears only when this function is activated.	Perform money declaration.	
E040	Issue guest receipt	Attempt to register a new transaction without issuing a guest receipt.	Issue a guest receipt.	
E046	REG buffer full	Registration buffer full.	Finalize the transaction.	
E049	CHECK memory full	Check tracking index memory full.	Finalize and close the check number currently used.	
E050	DETAIL memory full	Check tracking detail memory full.	Finalize and close the check number currently used.	
E051	CHK/TBL No. is occu-	Attempt to made use <new check=""> to open a new</new>	Finalize and close the check that is currently under the	
	pied	check using a number that is already used for an	number that you want to use or use a different check	
		existing check in check tracking memory.	number.	
E053	CHK/TBL No. is not	Attempt made to use <old check=""> reopen a new check</old>	Use the correct check number (if you want to reopen a	
-300	pened using a number that is not used for an existing check in		_	
	-	check tracking memory.	use <new check=""> to open a new check.</new>	
E075	Negative balance	Attempt to finalize a transaction when balance is less	Register item(s) until the balance becomes positive	
-3,3	cannot be finalized	than or equal to zero.	amount.	

Troubleshooting

Error code	Message	Meaning	Action	
E101	PLU maintenance file	Scanning PLU direct maintenance/batch maintenance	Terminate the maintenance.	
	full. Press <#2> to	file becomes full.		
	exit			
E103	PLU Code is not exist.	PLU code is not existed in the file.	Enter proper PLU code.	
	Input the PLU Code			
E105	PLU file full	Scanning PLU file full	Modify the designated item.	
E106	Item exists in the PLU	The designated item has already existed in the		
	FILE	scanning PLU file.		
E112	Close the journal	The journal platen arm is opened.	Close the journal platen arm.	
	platen arm			
E114	4 Close the receipt The receipt platen arm is opened.		Close the receipt platen arm.	
	platen arm			
E139	Negative balance is no	Attempt to register <-> or <cpn> when the balance</cpn>	Enter proper minus/coupon amount.	
	allowed	becomes negative.		
E146	Arrangement file full	Arrangement file is full.	Set the arrangement properly.	
E200	Insert RAC	RAC is set.	Set RAC.	
E201	Illegal Format	Illegally formatted RAC	Format the RAC.	
E202	File not found	The designated file is not found in the RAC.	Enter proper file name.	
E205	File already exist.	Can not write, because designated file has already been	Check the operation and retry.	
		in the RAC.		

When the cash drawer does not open!

In case of power failure or the machine is in malfunction, the cash drawer does not open automatically. Even in these cases, you can open the cash drawer by pulling drawer release lever (see below).




Important!

The drawer will not open, if it is locked with a drawer lock key.

When the register does not operate at all

Perform the following check whenever the cash register enter an error condition as soon as you switch it on. The results of this check are required by service personnel, so be sure to perform this check before you contact a CASIO representative for servicing.



Clearing a machine lock up

If you make a mistake in operation, the cash register may lock up to avoid damage to programs and preset data. Should it happens, you can use the following procedure to clear the lock up without losing any data.

- 1 Power off the register.
- 2 Insert the PGM key in the mode switch.
- 3 Press down FEED, and turn the mode switch to PGM mode.
- 4 The display shows 0.00, then release [FEED].
- 5 Press [SUB rotal], then issue a receipt.

In case of power failure

If the power supply to the cash register is cut by a power failure or any other reason, simply wait for power to be restored. The details of any ongoing transaction as well as all sales data in memory are protected by the memory backup batteries. (This is the reason to install the batteries.)

- Power failure during a registration
 - The subtotal for items registered up to the power failure is retained in memory. You will be able to continue with the registration when power is restored.
- Power failure during printing a read / reset report
 - The data already printed before the power failure is retained in memory. You will be able to issue a report when power is restored.
- Power failure during printing of a receipt / journal Printing will resume after power is restored. A line that was being printed when the power failure occurred is printed in full.
- - The power failure symbol is printed and any item that was being printed when the power failure occurred is reprinted in full.


Important!

Once receipt / journal printing or printing of a report starts, it can be stopped only by interruption of power to the cash register.

When the L sign appears on the display

About the low battery indicator...

The following shows the low battery indicator.



If this indicator appears when you switch the cash register on, it can mean one of three things:

- •No memory backup batteries are loaded in the cash register.
- •The power of the batteries loaded in the unit is below a certain level.
- •The batteries loaded in the unit are dead.

Important!

Whenever the low battery indicator appears on the display, load a set of two new batteries as soon as possible. If there is a power failure or you unplug the cash register when this indicator appears, you will lose all of your sales data and settings.


> BE SURE TO KEEP THE POWER CORD OF THE CASH REGISTER PLUGGED IN WHENEVER YOU REPLACE THE BATTERIES.


To replace journal paper



Step 1

Set the mode switch to the REG position and remove the printer cover.





Step 2

Press FEED to feed about 20 cm of paper.



Step 6

Slide the printed journal from the take-up reel.



Step 3

Cut the journal paper at the point where nothing is printed.



Step 7

Open the platen arm.




Step 4

Remove the journal takeup reel from its holder.



Step 8

Remove the old paper roll from the cash register.



Step 5

Remove the paper guide from the take-up reel.



Load new paper.


Go to the step 3 described on page 12 of this manual.

To replace receipt paper



Step 1

Set the mode switch to the REG position and remove the printer cover.





Step 2

Open the platen arm.



Step 3

Remove the old paper roll from the cash register.

Step 4

Load new paper.

Go to the step 3 described on page 11 of this manual.

Options

P-5880T roll paper

WT-89 wetproof cover

The optional wetproof cover protects the keyboard from moisture damage.

Consult your CASIO dealer for details.

Specifications

Input method

Entry: 10-key system, buffer memory 8 keys (2-key roll over)

Department: Full key system

Display

Main: Amount 10 digits (zero suppression); No. of repeats, total, change, transaction indicator

Descriptor 16 digits × 2 lines; item descriptor, No. of items, mode, clerk name

Customer: Amount 8 digits (zero suppression)

Printer

Receipt: Thermal alpha-numeric system 24 digits, receipt on/off key

Store name or slogan is printed automatically Journal: Thermal alpha-numeric system 24 digits

Automatic take up roll winding

Paper roll: $58 \text{ (W)} \times 80 \text{ (D)} \text{ mm}$ Paper thickness: $0.06 \sim 0.085 \text{ mm}$

Paper feed: Separate for receipt and journal

Print speed: About 14 l/s

Listing capacity

Amount: 99999999
Quantity: 9999.999
Tendered amount: 9999999999
Percent: 99.99
Tax rate: 9999.9999

Numbers: 999999999999999

Chronological data

Date print: Automatic date printout on receipt or journal, automatic calendar

Time print: Automatic time printout on receipt or journal, 24-hour system/12-hour system

Alarm

Key catch tone, error alarm, sentinel alarm

Memory protection battery

The effective service life of memory protection batteries (two new size AA alkaline batteries) is

approximately one year from installation into the machine.

Power supply/power consumption

See the rating plate.

Operation temperature

 $0^{\circ}\text{C} \sim 40^{\circ}\text{C} (32^{\circ}\text{F} \sim 104^{\circ}\text{F})$

Humidity

 $10 \sim 90\%$

Dimensions and weight

213mm (H) × 400mm (W) × 450mm (D) / 10kg (8.4" (H) × 15.7" (W) × 17.7" (D) / 22lbs.)

...with medium size drawer

		Contents				
Category	No. of Totalizers	Amount (10 digits)	No. of items (4 digits)	Count (4 digits)	No. of customers (4 digits)	Periodic Totalizer
Department	200	✓ *1	✓ *3			V
PLU	2000	✓ *1	✓ *3			
Hourly sales	24	✓ *1			✓ *4	
Monthly	31	✓ *1			✓ *4	
Clerk	50	✓ *1			✓ *4	
Transaction key & fix total		✓ *1 0	r 🗸 *4	or 🗸 *4	or 🗸 *4	V
Non resettable grand sales total	1	✓ *2				
Reset counter	8			✓ *4		V
Consecutive No.	1			✓ *4		

^{*1: -9,999,999.99 ~ 99,999,999.99 *2: -999,999,999.99 ~ 9,999,999,999.99 *3: -999.99 ~ 9999.99 *4: 1 ~ 9999}

^{*} Specifications and design are subject to change without notice.

Α		Е	
	alphabet key 53, 54		error correct 24
В		F	
	backlight 65		feed 24
	bottom message 26		fixed total report 45
	bottom message 20		flash report 78
С			function key 56
	cancel 24, 44		function key report 45
	CAPS key 53	_	Tunetion key report 15
	cash 24, 69	G	
	cash in drawer 45		general control program 60
	change 29		grand total 45, 59
	character enter key 53, 54		gross total 45
	character keyboard 53		group report 79
	character manual input 53		S · · · · · · · · · · · · · · · · · · ·
	charge 25, 38, 69	Н	
	check 24, 38, 69		hash 66, 68
	clear 24		help 24
	clear key 53, 54		high amount limit 31, 68
	clerk 46		high amount limitation 32
	clerk function 64		hourly report 78
	clerk name 57	- 1	-
	clerk number 24, 46, 72	•	
	commercial message 26		individual key report 74
	commission 66, 68, 73		item counter 26, 61
	compressed print 64	J	
	consecutive number 26, 60	Ū	
	correction 42, 43		journal 12, 26
	credit 25, 38, 72		journal skip 61
	credit balance 61	K	
	currency exchange 25, 48, 63, 71		1
	customer display 20, 22		key catch tone 61
D			key function program 66
_			keyboard 20
	daily sales X 20	L	
	daily sales X report 74		link 68
	daily sales Z 20		logo message 26
	daily sales Z report 45, 74		low digit limitation 66, 68
	daily X report 75		low digit inintation 60, 60
	daily Z report 17, 76	M	
	date 28		machine feature program 60
	date set 13		machine number 26, 60
	delete key 53, 54 department 25, 29, 56, 66, 67, 74		magnetic plate 20
	•		main display 20, 22
	department number 25, 30 department report 45		memory protection 10
	department shift 25, 30		merchandise subtotal 39, 70
	descriptor 52		message 57
	descriptor 52 descriptors by list 52		message control 64
	discount 24, 36, 70		mixed tender 38
	display 22		mode switch 20, 21
	double size letter key 53, 54		monthly report 78
	double Z report 63		multi tapping 54
	drawer 20		multiplication 24, 30, 34
	drawer key 20		multiplication / for 24, 30, 35, 7
	drawer lock 20		_

Index

N		right cursor key 54
	nagativa prica 66, 69	roll paper 20
	negative price 66, 68 net total 45	S
	no sale 41	shift lray 52
	non-add / no sale 70	shift key 53 sign off 24, 46
	non-add / no sale 25	sign on 46
_		single item 29, 34, 47, 66, 68
0		space key 54
	OFF mode 20	special character 59
	open 25	stand-by 20
	open PLU 35, 66, 68	status indicator 23
	operator key 20	subdepartment 24
Р		subtotal 24, 29, 70
•		subtotal compulsory 61
	paid out 24, 41, 69	_
	paper install 11	Т
	periodic sale X/Z 20	take-up reel 12, 20
	periodic sales X report 80	tax program 24
	periodic sales Z report 80	tax shift 25, 39, 71
	PGM mode 20	tax status 31, 33, 36, 37
	platen 11	tax system 60
	PLU 24, 33, 66, 67, 74 PLU report 78	tax table 14
	pop-up display 20, 21	taxable status 68
	post receipt 24	thermal paper 11
	premium 25, 50, 70	time 28
	preset graphic 26, 52, 64	time set 13
	preset message 26, 52, 64	training clerk 72
	preset price 32	U
	preset tax status 32	unit price 29, 31, 33
	price 24	
	print control 61, 62, 63, 64	W
	printer 20	watermark 16
	printer cover 20	X
	program backup 16	
	program end key 53, 54	X mode 20, 74
	program key 20	X2/Z2 mode 20, 80
	program mode 20	Z
	program report 82	7 1. 20 74
R		Z mode 20, 74
	rate 36	zero skip 63 zero unit price 66, 68
	receipt 11, 26	zero unit price 66, 68
	receipt control 64	
	receipt on/off 24	
	received on account 24, 41, 69	
	reduction 24, 37, 70	
	refund 24, 40	
	refund mode 20	
	REG mode 20	
	register mode 20	
	repeat 23, 29, 34	
	report 74	
	report descriptor 58	
	report sample 77	
	report title 45, 59 RF mode 20, 40	

LIMITED WARRANTY: ELECTRONIC CASH REGISTERS

This product, except the battery, is warranted by Casio to the original purchaser to be free from defects in material and workmanship under normal use for a period, from the data of purchase, of one year for parts and 90 days for labor. For one year, upon proof of purchase, the product will be repaired or replaced (with the same or a similar model) at Casio's option, at a Casio Authorized Service Center without charge for parts. Labor will be provided without charge for 90 days. The terminal resident software and programmable software, if any, included with this product or any programmable software which may be licensed by Casio or one of its authorized dealers, is warranted by Casio to the original licensee for a period of ninety (90) days from the date of license to conform substantially to published specifications and documentation provided it is used with the Casio hardware and software for which it is designed.

For a period of ninety (90) days, upon proof of license, Casio will, at its option, replace defective terminal resident software or programmable software, correct significant program errors, or refund the license fee for such software. Significant program errors will be significant deviations from written documentation or specifications. These are your sole remedies for any breach of warranty. In no event will Casio's liability exceed the license fee, if any, for such software. This warranty will not apply if the product has been misused, abused, or altered.

Without limiting the foregoing, battery leakage, bending of the unit, a broken display tube, and any cracks or breaks in the display will be presumed to have resulted from misuse or abuse. To obtain warranty service you must take or ship the product, freight prepaid, with a copy of the sales receipt or other proof of purchase and the date of purchase, to a Casio Authorized Service Center. Due to the possibility of damage or loss, it is recommended when shipping the product to a Casio Authorized Service Center that you package the product securely and ship it insured. CASIO HEREBY EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE. NO RESPONSIBILITY IS ASSUMED FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION DAMAGES RESULTING FROM MATHEMATICAL INACCURACY OF THE PRODUCT OR LOSS OF STORED DATA. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. This warranty gives you specific rights, and you may also have other rights which vary from state to state.

CASIO, INC. 570 MOUNT PLEASANT AVENUE, P. O. BOX 7000, DOVER, NEW JERSEY 07801 U.S.A.

Model:	.Serial Number:	Date of Purchase:
Your Name:		
Address:		
Dealer's Name:		
Address:		

